## **Operating Instructions 5F & 10F Measuring Wheels**

- 1) Hold handle grips with hands extended slightly forward and downward in a natural walking position and to where measurement is to begin.
- 2) Turn counter reset knob forward (clockwise) until all digits read zero.
- 3) Whenever possible, select an object in the distance toward which you can walk while traversing the ground being measured. This will enable you to maintain a straight line.
- 4) When measuring on a gravel road or rough ground, the operator should walk at a slower pace so the wheel does not bounce.
- 5) At the end of measurement, take the reading while holding handle in the same position as at the start of measurement. Note: The counter indicates the distance in feet.



## **Measuring Tips**

Gandy Company 815 Rice Lake Street Owatonna, MN 55060 Website: www.gandy.net



Phone: 507-451-5430 800-443-2476 Fax: 507-451-2857 Email: sales@gandy.net